



FROJECT

NOTE:

1. Place geocomposite sheet drains in 3-foot minimum wide strips with a spacing to achieve $30\% \pm 5\%$ coverage area on excavation backslope to $\frac{2}{3}H$.

2. Connect collector pipe to outlet pipes using a tconnector and outlet at low points of wall and at 50foot maximum spacing. Provide collector pipe, outlet pipe, and fittings meeting the requirements of Subsection 708.04.

3. Cover the end of the outlet pipe with screen according to Subsection 605.03. Hold the screen securely in place with standard coupling bands or approved means with securing screws.

4. Mark the exposed end of the outlet pipe with a 4-foot long post or other suitable marker. Place post within 12 inches of the end of the pipe.

5. Spacing and use of stiffener to be determined by the manufacturer.

6. Welded wire reinforcement systems require a top reinforcement mat unless the wall facing uses stiffeners to adequately reinforce the wall face.

